

MODALO®

Automatic Watch Winders  
Users Manual

## MODALO®

The MODALO® GmbH with its headquarters in the city of Hamburg (Germany) is the top address for high quality watch winders, watch boxes and exclusive business leather bags.

A watch winder depends on much more than just rotation. Especially with heavy watch models, a watch winder is needed with the right technology and quality in order to cope with the weight (of the watch). With its certified Registered trademark MODALO®, the MODALO® GmbH is both a leading manufacturer and retailer of watch winders and watch boxes.

So that the workings of automatic watches do not come to a standstill, they have to be constantly kept moving. This is naturally ensured by wearing them (on the wrist). There are situations where a wristwatch will be taken off for a longer period of time. For example many owners leave their expensive watch at home to reduce the risk of theft on a holiday trip.

Many people own more than one watch and like to switch between different models. With a watch winder one can save resetting the watch before every use. Especially when the watch has a date or calendar display, this can be a nuisance. MODALO®'s watch winders are the ideal storage place for each timepiece (as well).

Like the luxury pieces they keep moving, MODALO® watch winders have just as much of a wow factor with their glossy piano-style finish. Different rotational modes match each winding type. There are models for a single watch up to watch winders with eight watches. The interior of each MODALO® watch winder is made of premium synthetic leather or suede. The mains or battery-powered models are noted for having quiet running modes.

## SUMMARY

Title	page
Thank you	1
General Information	2
Instructions for Type-1 (knobs)	3-4
Instructions for Type-2 (buttons)	5-6
Instructions for Type-3 (Touch)	7-8
Statement of Limited Warranty / Guarantee	9

## THANK YOU

### Congratulations on your purchase of a MODALO® watch winder!

This new product has been designed and constructed in the usual high quality and very demanding tradition of the MODALO® GmbH, in order to fulfill the high expectations of exclusive watch brands. Thank you for purchasing this product and we hope that you will be completely satisfied with it.

## IMPORTANT - PLEASE READ

Please read the manual carefully and follow all the instructions before starting operation. Please keep this manual for future reference. The manufacturer's warranty is valid for 24 months from the date of purchase. Shipping, returns and repairs as described in the Terms and Conditions.

## GENERAL INSTRUCTIONS

### Usage and technical details

Your MODALO® watch winder has been especially designed to store and prolong the function of all automatic watches. The MODALO® watch winder enables a certain number of left-sided, right-sided or both left and right -sided rotations per day, in order to ensure continual functioning.

---

Batteries, electronic devices and parts of equipment do not belong in the trash, but should be disposed of in accordance to local laws and regulations. Let dealer in your area preferably dispose of these items.

---




The Watch Winder has a program cycle of about 24 hours and then pauses, before starting automatically the following day. The built-in timer makes sure that the daily intervals are kept.

## OPERATING INSTRUCTIONS TYPE 1 (KNOBS)

1 Obtain information first on how many turns per day (TPD) your watch needs to function optimally. Please contact your watch manufacturer if you are unsure.

2 Either connect the watch winder to the power socket using the supplied AC adapter, or insert the provided batteries into the relevant model. Load the watches onto one or more of the watch turntables. When changing watches always switch off the rotation!



Positioning of  
the watch

### SETTING OF THE KNOB

#### Position 1

Power Off / Off

#### Position 2

Rotates approx. 1 minute and 25 seconds clockwise, pauses about 14 Minutes and 35 seconds, then repetition (about 900 revolutions / day).

#### Position 3


Rotates approx. 1 minute and 25 seconds counterclockwise, pauses about 14 Minutes and 35 seconds, then repetition (about 900 revolutions / day).





#### Position 4

Rotates approx. 1 minute and 25 seconds clockwise, pauses about 7 minutes and 35 Seconds, rotates about 1 minute and 25 seconds counterclockwise, pauses about 7 minutes 35 seconds, then repetition (about 1700 revolutions / day).

#### Position 5

Approx. Four hours alternately: rotates 1 minute and 25 seconds clockwise, pauses about 3 minutes and 35 seconds, then rotates about 1 minute and 25 seconds counterclockwise, pauses about 3 minutes and 35 seconds, then pauses 8 hours, (About 900 revolutions / day).




-  Off
-  Clockwise
-  Counterclockwise
-  Reverse direction

## OPERATING INSTRUCTIONS TYPE-2 (KEY OPERATION)

1. Obtain information first on how many turns per day (TPD) your watch needs to function optimally. Please contact your watch manufacturer if you are unsure.

2. Either connect the watch winder to the power socket using the supplied AC adapter, or insert the provided batteries into the relevant model. Load one or more of the watch turntables with watches. When changing watches always switch off the rotation!



Positioning of the watch

Adjusting the button operation

### 1. TPD button (on top)

Press the upper TPD button to select the desired number of revolutions per day (TPD) to select revolutions per day, in steps of 650 - 1000. The revolution programs selected are in a figure of eight form. The illuminated LED indicates the current selected RPM speed.

## ADJUSTING THE BUTTON OPERATION

### 1. TPD button (on top)

Press the upper TPD button to select the desired number of revolutions per day (TPD) to select revolutions per day, in steps of 650 - 1000.

The revolution programs selected are in a figure of eight form. The illuminated LED indicates the current selected RPM speed.

### 2. DIRECTION button (below)


Press the lower DIRECTION button to select the desired rotational mode. Select either figure of eight rotation or switch off the watch winder. The LED displays the selected rotational mode.



## OPERATING INSTRUCTIONS TYPE-3 (TOUCH OPERATION)

1. Obtain information first on how many turns per day (TPD) your watch needs to function optimally. Please contact your watch manufacturer if you are unsure.

2. Either connect the watch winder to the power socket using the supplied AC adapter, or insert the provided batteries into the relevant model. Load one or more of the watch turntables with watches. When changing watches always switch off the rotation!



Positioning of the watch

### ADJUSTMENT VIA TOUCH-OPERATION

#### 1. ON / OFF

Start or stop the watch winder by touching ON / OFF on the play icon ▶ or stop symbol ■.

#### 2. DIRECTION

Using DIRECTION on the touch panel to select the rotational programs, ↻ clockwise-, ↺ counterclockwise- and ⌚ time-controlled directional changes.

#### 3. TPD

Touch TPD to select the daily desired rotational speed between 650 - 1000 rpm.

#### 4. LINE

Touch LINE to set the desired turntable for several watches separately. The small numbers (1-8) indicate which turntables are currently operating.

When the symbol for batteries  lights up, the batteries are due to be replaced (only for devices with battery operation).



### PLEASE NOTE

Always touch the middle of the touch panel (See figure).

## STATEMENT OF LIMITED LIABILITY / GUARANTEE

Failure to follow these instructions, and in particular in the case of improper usage by impact or shock, unauthorized intrusion into the unit, as well as fire, water and other elemental damage will void the warranty. The warranty will also not cover damages or scratches resulting to the surface of the product.

The warranty is subject to the statutory provisions and is for two years. Any defects must be reported immediately to **MODALO®** GmbH. Within a period of two weeks after receipt of the goods the customer has to register the product using the delivery note or invoice.

The **MODALO®** warranty on watch winders covers material and manufacturing defects, but excludes the glass pane, gloss coating and batteries, as well as damage caused by improper usage such as water damage, lack of care, accidents, normal wear and increased noise, as well as for any consequential loss caused by the malfunctioning or failure of the product.

Subject to technical and visual changes.

MODALO®

MODALO®

